



## **Cleanflow Free Standing Tabletop Automatic Hand Sanitiser Gel Dispenser IFSZYX01**

### **Operating Instructions**

1. Place 4pcs "AAA" batteries in the battery compartment according to the polarity (+/-) marked on the battery compartment.
2. Undo the screws on the top cover, fill the container with alcohol gel hand sanitiser to a suitable level. (Make sure the alcohol gel hand sanitiser doesn't contain any solid particles). Replace the top cover and the screws.
3. Press the On/Off button until the indicator light turns red. The dispenser is now in working mode. Place your hands under the nozzle (within an 8cm distance from the sensor), the indicator light turns red. The default setting is a 1 second dispense of alcohol gel hand sanitiser.
4. To increase the alcohol gel hand sanitiser dispense duration to 2 seconds, press the On/Off button again until the red indicator light flashes twice.
5. To increase the alcohol gel hand sanitiser dispense duration to 2.5 seconds, press the On/Off button again until the red indicator light flashes three times.
6. To turn off the dispenser completely, press and hold the On/Off button for 3 seconds until the indicator light turns off.



### **Warning**

1. After each refill of alcohol gel hand sanitiser, please activate the sensor between 3 – 10 times to make sure the dispense tube is free of air.
2. Make sure the dispenser is regularly filled up for optimal operation.
3. Do not use excessive force on the dispenser as this may cause damage.
4. If the dispenser will not be used for a significant period of time, it is advised to remove the batteries. Always remove drained batteries and dispose of safely.
5. Keep the dispenser upright to avoid any spillage of alcohol gel hand sanitiser.
6. Only suitable for indoor use. Avoid direct sunlight.
7. Do not wash or immerse the unit in water. It may be cleaned with a damp cloth.